



# SilverFast 9

## - Keyboard Shortcuts -

[SHIFT] =

[BACKSPACE] =

### SilverFast 9 Shortcuts

Set Source to Positive (for transparent only)

[CTRL] + [1]

Set Source to Kodachrome (for transparent only)

[CTRL] + [2]

Set Source to Negative (for transparent only)

[CTRL] + [3]

Start Prescan

[CTRL] + [SHIFT] + [S]

Cancel Prescan

[CTRL] + [X]

Start Scan / Process

[CTRL] + [S]

Start Batch Scan / Process

[CTRL] + [ALT] + [S]

Activate / Deactivate WorkflowPilot

[CTRL] + [SHIFT] + [W]

Open JobManager

[CTRL] + [J]

Apply Standard Automatic "Auto"

[SHIFT] + [A]

Apply Standard Automatic with Color  
Cast Removal "Auto CCR"

[CTRL] + [SHIFT] + [A]

Set Neutral Point

[CTRL] + [N] +

Reset Automatic	<b>CTRL</b> + <b>ALT</b> + <b>A</b>
Set/Edit/Delete Densitometer Point	<b>SHIFT</b> + <b>ALT</b> + 
Show Histogram Dialog	<b>CTRL</b> + <b>SHIFT</b> + <b>H</b>
Show Gradation Dialog	<b>CTRL</b> + <b>G</b>
Show Global Color Correction Dialog	<b>CTRL</b> + <b>B</b>
Show Selective Color Correction Dialog	<b>CTRL</b> + <b>E</b>
Show USM Dialog	<b>CTRL</b> + <b>U</b>
Activate / Deactivate SoftProof	<b>CTRL</b> + <b>SHIFT</b> + <b>Y</b>
Show Image Information	<b>CTRL</b> + <b>I</b>
Open Preferences	<b>CTRL</b> + <b>,</b>
Open PrinTao	<b>CTRL</b> + <b>P</b>
Undo	<b>CTRL</b> + <b>Z</b>
Redo	<b>CTRL</b> + <b>Y</b>
Show infrared Image <small>(requires iSRD 100% preview, press keys and click in the preview)</small>	<b>CTRL</b> + <b>SHIFT</b> + 
Show / Hide Masks	<b>CTRL</b> + <b>M</b>
Find Frames for Slide Holder 35mm	<b>CTRL</b> + <b>SHIFT</b> + <b>F</b>
Find Frames for Filmstrip Holder 35mm	<b>CTRL</b> + <b>ALT</b> + <b>F</b>
Find all Frames	<b>CTRL</b> + <b>F</b>

Duplicate Frame

**CTRL** + **D**

Duplicate Frame

(Click & move Source Frame to where the Duplicate should go)

**ALT** +  Move Frame

Copy & Paste Frame

(Click Source Frame, then copy & paste on empty area)

**ALT** +  Source +  Target

Copy & Paste Frame

(Click Source Frame, then copy & paste on empty area)

**CTRL** + **C**, **CTRL** + **V**

Copy & Paste Frame settings

(Click Source Frame, then copy, select target frame and paste)

**CTRL** + **C**, **CTRL** + **V**

Flip Orientation

**CTRL** + **R**

Maximize Frame

**ALT** + **A**

Adjust Frame & keep aspect Ratio

**SHIFT** +  Adjust one side

Select next Frame

**ALT** + 

Select previous Frame

**ALT** + 

Zoom to Frame

**CTRL** + 

Zoom out

**CTRL** + 

Zoom to Selection

**CTRL** +  Draw Frame

Reset all Adjustments of active Frame

**CTRL** + **SHIFT** + **R**

Delete Frame

**CTRL** + **BACKSPACE**

Delete All Frames

**CTRL** + **SHIFT** + **BACKSPACE**

Rotate Preview 90° counterclockwise

+

Rotate Preview 90° clockwise

+

Flip Preview vertically

+

Flip Preview horizontally

+ +

Quit

+

## SilverFast HDR Specifics:

Open Files

+

Open Files

+ (VLT Button)

Refresh Preview

+ (VLT Button)

## PrinTao Specifics

Print

+

Close PrinTao

+

Show Tutorial Video

Rotate Frame 90° counterclockwise

+

Rotate Frame 90° clockwise

+

Flip Frame vertically

+

Flip Frame horizontally 

Center Frame 

Fit Frame to Page 

Font Settings 

Toggle Bold 

Toggle Italic 

Toggle Underlined 

Toggle Striked Through 

Text Bigger 

Text Smaller 

Zoom In 

Zoom Out 