

*Chapter 7*

*Color Management*



## 7. Colour Management

*This chapter describes the concept of colour management, how to set up the appropriate settings in SilverFast, and how to calibrate your scanner to get precise colours.*

<b>7.1 Colour Management</b>	<b>413</b>
<b>7.2 Calibration of your Scanner using SilverFast IT8 Calibration</b>	<b>433</b>
<b>7.3 Addendum</b>	<b>442</b>
<b>7.4 Index</b>	<b>460</b>
<b>7.5 Glossary</b>	<b>482</b>

# 7.1 Colour Management

## Introduction


In the past getting professional results with colour reproduction was only achieved by highly educated professionals. There have been two major reasons for this:

1. Devices for colour reproduction demanded high investments
2. Operation of devices was complicated - complex Know-How was necessary.

Luckily the above mentioned reasons are not valid any more today, because the devices needed as, scanner, PC, printer have become affordable for almost everyone. Also operation has become easy with intelligent software and colour management matured.

### Objective of Colour Management System (CMS)

Professional workflow without colour management is not conceivable any more today. To save time and money it is desired to see the result of the final scan on the monitor or printer already on the preview. Since every input- and output-device has its own colour gamut, one cannot assume colours to be consistent.



### What is an ICC Profile?

An ICC profile characterizes the colour space behaviour of a device. An ICC profile is a data file and will be used to calibrate the device.

### What is IT8?

IT8 is an industry standard test-form designed to measure the performance of input devices and generate ICC profiles.

This is where a CMS becomes relevant. A dedicated ICC profile has to be generated for every input- and output device describing their colour space behaviour. Within the workflow the colour management System compares two profiles, that of the data sender, i.e. a scanners, with that of the data receiver, i.e. a monitor, and calculates a relation for the conversion, which will translate the image data into the right colour impression.

## Objective of the *SilverFast* Colour Management

*SilverFast* differs from the majority of scan software by its functional power. With reference to colour management *SilverFast* offers three significant functions:

### 1. Automatic Matching with Photoshop

The high level of integration of *SilverFast*'s architecture into the Adobe Photoshop 5 architecture, assures matching of the *SilverFast* preview with the final result in Photoshop. This is a very important highlight of *SilverFast*, because only this function makes sure that the user can predetermine (and control) his final result from the *SilverFast* preview.


### 2. Safe IT8 Calibration (optional) with ICC Profiler

With *SilverFastAi* you can create a dedicated ICC profile for your scanner so your scanner can be used within the colour management workflow. *LaserSoft Imaging AG* offers (optional) IT8 calibration for all full versions of *SilverFast*.

*SilverFast*'s IT8 calibration is integrated into the *SilverFast* application in such a way excluding any possible mis-operation.

### 3. Individual Colour Control with Selective Colour Correction


*SilverFast*'s selective colour correction enables the user to change individual colours independently on the *SilverFast* preview. Controlling the colours of the final result at a very professional level without trial and error and integrated with the colour management, is a real boon for any level of user.



### Note!

Do not select sRGB as your default colour space in Photoshop if you intend to do colour reproduction with printing.

Obviously there are limits to the ability to display the same data on different devices the same way. The different colour spaces have varying dimensions, i.e. displaying different amount of colours. Also the colour shades they can display are varying. This is resulting in colour deviations from the conversion. The colour space "sRGB", which Photoshop offers as a default colour in its set up is very small, so that even the small colour space of a printer will not be properly rendered. sRGB colour space is still big enough for any monitor. Making sRGB a suitable colour space for the internet. For any documents containing images, which have to be printed, sRGB is not suitable. Use Apple RGB or Adobe RGB instead.



### Comparing the colour spaces

Shown is a projection of the colour spaces on to a surface. The „curved triangle“ represents the L\*a\*b\* colour space, which contains all visible colours.

**SilverFast** offers different possibilities for work flow integration. On the system level under ColorSync (Mac) or ICM (Windows98/2000/XP), or in with integration into the application - in general as realized with Photoshop. CMYK output can already on the preview be checked by *SilverFast's* softproof function.

## The CMS Dialogue



Clicking on the “Options...” button in the “General” palette brings you to the basic settings dialogue. Among others you will find the CMS card, where you can adjust the colour management settings.

### The “CMS” Palette has Four Different Sections

#### 1. Colour Management

Here you can define whether and how *SilverFast* will communicate with its imaging functions and the different devices (scanner, digital camera, monitor, printer).

#### 2. Profiles for ColorSync (ICM)

In case you have chosen ColorSync (Windows: ICM) as your preferred colour management system, you have to define the in- and output profiles for the different devices here.

#### 3. Embedded ICC Profiles

Here you will define whether *SilverFast* will embed a profile into the output data in order to render colours on another output device correctly at a later instant.


The name of the embedded profile in the current image is also displayed in ***SilverFastHDR...***, ***-DC...***

#### 4. Plug&Play CMYK

When using P&P CMYK you have to choose a separation ICC (CMYK) output profile to separate your images for the printer.




CMS palette in SilverFastAi



CMS palette in SilverFastHDR

## 1. Colour Management

### Scanner -> Internal




Here you define how your scanner's colour space will be matched to your system. You decide whether the original scan will be transferred to the imaging application with accurate colours.

**<NONE>:** You renounce matching of the scanner colour space to the colour space of the imaging software. Colours on the monitor may deviate from the image sample.

**ColorSync / ICM:** You decide to integrate the scanner into the operating system's colour management. By selecting the right ICC profile images will be scanned colour-exact. With *SilverFast's* IT8 calibration you can generate a profile describing your scanner (your scanner's colour gamut).

### Internal --> Monitor




Here you define whether and how the monitor is matched to your system. You have to make sure that the work flow is consistent with the colour settings in your imaging application (e.g. Photoshop).

**<NONE>:** Data will be passed on to the monitor without any matching. You do omit colour management. Specially with Photoshop 5 it is very likely, that the *SilverFast* preview will deviate significantly from the results in Photoshop.

**Automatic:** You rely on Photoshop to do the matching to your monitor. It is advised, to set the same colour space (e.g. Adobe RGB) under "Profiles for ColorSync (ICM)" in the field "internal", you have defined inside Photoshop. Otherwise the colour of the scan data could deviate. Since the Twain-standard does not support such functions, it is not available with the *SilverFast* Twain-module!

**ColorSync / ICM:** You are integrating the monitor into the OS's colour management. The appropriate ICC profile for your monitor will be required. More sophisticated monitors get one supplied on disk or CD, if not, you might get it through the internet from the manufacturers web site, last resort would be to create one with a spectro-photometer. Adobe Photoshop 5 enables you to do your own monitor calibration (ICC profile). For this, utilise the installed Photoshop tool „Adobe gamma“ or, as a professional solution, use respective measurement tools.



### Internal ->Output

Here you can define what type of data the printer will get from **SilverFast**. Data to be transferred to the imaging application (e.g. Photoshop), can be in different formats. CMYK- and RGB-files can have profiles embedded, so the data will be matched to the printer's colour space accordingly.

**RGB:** You can output data in RGB-data format. This setting is recommended for users having no Postscript- but other printers or have no printer ICC profile, or for those using their scans merely for internet- or multimedia projects.


**ColorSync / ICM:** You are integrating your printer into the OS's colour management. The appropriate ICC profile for your printer will be required.

**Lab CIE-L\*a\*b\*** is a device-independent colour space, representing all visible colours. Colour differences are not rendered very detailed, and many colours cannot be displayed on a monitor (see also graphic in introduction: the "curved rectangle" represents Lab).

**P&P CMYK:** High quality system to get CMYK data directly from the 4-colour separation built into **SilverFast**. To get precise colours it is vital to select the same CMYK colour space in Photoshop, (defined by the same ICC profile), as in **SilverFast**.

## 2. Profiles for ColorSync (ICM)

Only when you have chosen ColorSync (ICM) for colour management, you will have to select under “ColorSync profiles” the appropriate profiles for your device here. Exception is with the menu option “Internal ---> Monitor” which has to have an ICC profile allocated to under “Internal”.




### Scanner (Reflective), Scanner (Transparency)

Here you allocate the appropriate (input) scanner profiles, which you have created with *SilverFast* or you have received from the scanner manufacturer. The profiles generated by *SilverFast* have the following naming convention:


SF\_R (Scanner name) or SF\_T (Scanner name)

Where the “R” stands for reflective, and the “T” for transparency. In brackets after these again are the scanner names. Profiles of hardware manufacturer do not follow standard structure. You will mostly find the name of the device where the file-suffix is „.icc” or „.icm”, does not have any significance, since the internal format is fully compatible.




#### Film scanner

Only then option “Scanner (Transparency)” is available



#### Flatbed scanner with transparency unit

Both options are available here:  
“Scanner (transparency)” as well as  
“Scanner (reflective)”




#### Flatbed scanner without transparency unit as well as SilverFastHDR, -DC, -PhotoCD.

Again, only one option is available:  
“Scanner (reflective)”

## Internal


The internal colour space is independent from any device connected and is defined by a profile. This defines the colour matching foundation the colour management is building upon.. For the majority of users it is advised to select the monitor colour space in order to unburden the computer.

Once you have selected Internal --> Monitor ColorSync (ICM) you have to define the internal colour space by a profile you can select freely. In case you have chosen "Automatic" under "Internal", select the profile of the application's internal colour space. The Photoshop plug-in leaves the monitor matching to Photoshop.




## Grey

Here you can select a grey profile for greyscale scans, which can also be embedded into the image file.




## Output/Printer




The integration of the printer into the colour management is the highlight, but also the part inducing the most difficulties. The scanner's colour space and the monitor's are the same in principle – RGB – there may be small differences in size, and the related white points are shifted against each other. The printer behaves differently: the output is not only depending on the inks but also on the paper stock - how is the paper white, how is the paper absorbency. All this information has to be considered by the profile. The modern inkjet printers are equipped with drivers, which generally take these issues into account, but they can not so well be integrated with ColorSync .


After having chosen Internal-->Output ColorSync (ICM) under colour management, you have to select the output profile of your printer or imagesetter here. This profile can be embedded into the file at your request.



*Profile-Embedding with Output on Non-PostScript-Printer*



*Profile-Embedding with Output on PostScript-Printer*



## “Rendering intent” for ICC-Profiles


“Profiles for ColorSync (ICM)” now has an additional popup menu in the “CMS” tab of the “Options...” dialogue. Now *SilverFast*’s “Rendering Intent”, which can be utilized for all ColorSync / ICM operations, can be switched on.

A differentiation of the Rendering Intent for various operations (i.e., input, monitor and output matching) is not possible.

Prior to this, *SilverFast* has utilized the Rendering Intent which was preset in the profile, thus generally “Perceptual Match.”

Instead of this default setting, one of the three other Rendering Intents supported by ColorSync / ICM, such as “relative colourimetric,” “saturation” and “absolute colourimetric” can be chosen. In comparison, the effect, when choosing “absolute colourimetric” appears to be the most similar to prior behaviour, because of the differences of the Media white points that appear here.

Image data, which has been produced from computer graphics or from renderings might require adaption of the Rendering Intent.




## Rendering Intents

### 1. Perceptual

Relative colourimetry is used. A reproduction which provides a perceptual or pleasing appearance. This general means both in- and out-of-gamut colours are modified from their colourimetric representation.


Example usage would be for scanned images.



## 2. Relative Colourimetric

Relative colourimetry is used. For reflection print this means that “y” of paper (paper white) is taken to be “1”. All colourimetric measurements are normalized based on the paper’s colourimetry. A colourimetric reproduction is provided for in-gamut colours. Out-of-gamut colours are mapped to the border of the reproducible gamut. This has the advantage of providing a larger effective gamut so that bright colours will more likely to be in-gamut. It has the disadvantage of sacrificing exact colour matches for printers with different paper white points.


Example usage would be for spot colours where a colour reproduction relative to the paper’s white is desired.



## 3. Saturation

Saturation relative colourimetry is used. A reproduction in which saturation is emphasized. In-gamut colours may or may not be colourimetric.

Example usage would be for business graphics where saturation is the most important attribute of colour.



## 4. Absolute Colourimetric

Absolute colourimetry is used. For reflection print this means that “y” (paper white) of printed paper is less than “1”. A colourimetric reproduction is provided for in-gamut colours. Out-of-gamut colours are mapped to the border of the reproducible gamut. This has the advantage of providing exact colour matches from printer to printer. It has the disadvantage of causing colours with “y” values between the paper’s white and “1” to be out-of-gamut.

Example usage would be for spot colours where an exact colour reproduction is desired.

### 3. Embedded ICC Profiles

Nowadays, digital images are transferred in various channels onto different computers. To assure the rendering of colours to be true without knowing from where they came and how they have been processed, images get a profile attached which will assure a basis for the colour reproduction process.

If you want to embed the ICC profile into the data, you have to check this field accordingly. You will automatically see which profile will be embedded.


There are four possible origins for an ICC profile:

1. When selecting RGB in the section colour management under Internal->Output the profile originates from the field Profiles for ColorSync --> Internal (e.g. Adobe RGB).
2. When selecting ColorSync (ICM) under Internal-->Output, the profile originates from the field Output/Printer in the field "Profiles for ColorSync". (e.g. "Euroscale coated.icc").
3. If "P&P CMYK" is selected, it is the profile that was chosen under "Plug&Play CMYK".
4. When scanning in 48 bit mode and having selected the scanner-profile under "Profiles for ColorSync", the scanner profile will be embedded into the file.



#### Working in 48 bit mode?

*SilverFastAi can embed a scanner profile (which describes the deviation of the scanner) into the Tiff data during the output of 48 bit data. The scanner deviations can then automatically be corrected during later processing with SilverFastHDR.*



*Embedding a Scanner-Profile into the 48bit RGB-File*

## 4. Plug&Play CMYK


### Scanning with Colour Separation

**LaserSoft Imaging AG** has developed a new solution for high-end separation through Plug&Play CMYK. A new and revolutionary technique solved the problem of separation because the CMYK preview always used to look too different from the final result. Not so with **SilverFast!**

The following diagram explains the functionality of the new separation:

1. RGB data is internally calculated to the hardware independent Lab colour space. Monitor settings are taken into account. The monitor should therefore always be adjusted properly (see below).
2. By using **SilverFast separation** as well as the Photoshop separation profiles with help of the ICC profile, we calculate via the Lab format into CMYK.

### SilverFast Plug&Play Separation



## CMYK Output with Colour Management


### Plug&Play CMYK Separation

In order to activate the P&P CMYK separation, proceed as follows: Select Internal->Output” “P&P CMYK” under the **SilverFast** colour management dialogue. Under "Plug&Play CMYK" at the bottom of the dialogue, select the appropriate profile.


The ICC-CMYK output profile can be chosen at the base of the CMS dialogue.

Make sure you have loaded the same profile in Photoshop under "Colour Settings -->CMYK setup".


When leaving the "Options..." dialogue, the button "Scan RGB" will now show "Scan CMYK".




Selection of monitor setting



Selection of P+P CMYK



Selection of same profile or separation table




You may also switch **SilverFast** from RGB to CMYK by keeping the "CTRL" key pressed and click on the "Scan" button. A small popup window will appear in which the choice can be made. (refer also "Permanent softproof" Pages 87 and 191) If you have not selected a separation table or ICC profile previously, the selection will be grey and cannot be activated.

### RGB-CMYK Toggling

Under Windows press right Mouse-button

### Softproof - CMYK Simulation

"Alt"-command and click into preview



Button for switching on / off the softproof function

### CMYK Colour Simulation on the Preview (CMYK Softproof)

When the scan button shows "Scan CMYK", you can switch the preview to CMYK simulation by clicking the softproof button within the densitometer window.

## Example Settings SilverFast/Photoshop 5.02

Following is a selection of example settings for the **SilverFast** CMS dialogue with reference to Photoshop 5.02:

### RGB Output under Photoshop without Colour Management

Under „Photoshop File/Colour Settings/ RGB Setup” you have selected e.g.: ❶ Adobe RGB as your working colour space. An ICC profile for this colour space should be exported, so you can select it later in *SilverFast*. To do this, you can save the settings with „save” into the ICC folder of the operating system.

Now bring up *SilverFast* (from the Photoshop “Import” menu). Go to “CMS” under “Options...” in the *SilverFast* main dialogue.

In “Colour management” select ❷ “Automatic” under “Internal --> Monitor”. Select ❸ “RGB” under “Internal --> Output”. In this case select ❹ <NONE> or “Calibration” under “Scanner->Internal”. You can only use Calibration with *SilverFast*’s own IT8 calibration. In this example we left it at <NONE>.

Select ❺ Adobe RGB under “Internal” in section “Profiles for ColorSync” as the RGB profile, which you have selected previously in Photoshop.



### RGB-Output with Colour Management

You have selected an RGB colour space (e.g.: Adobe RGB) under “Photoshop /Colour Settings/ RGB Setup”. For this you should have an ICC profile defining this colour space in which you can select later in the *SilverFast* CMS dialogue under “Profiles for ColorSync / ICM” - “Internal”. (If you do not have this profile, use “save” to save the profile into the System’s profile folder.)


Now bring up *SilverFast* (from “Import menu”) .

Go to “CMS” under “Options...” in the *SilverFast*’s main dialogue. Select ❶ “ColorSync”(ICM) in the “Colour management” section under Internal -> Monitor and Internal --> Output. Scanner->Internal is also set to ❷ “ColorSync” (ICM) in our example. This is only possible, if you have a Scanner ICC profile - either from *SilverFast*’s IT8 calibration, or supplied from the scanner manufacturer. The profiles of the hardware manufacturer are not very accurate, since they are more generalized instead of scanner specific.





Select the scanner profiles ③ (reflective/transparency) of your scanner in section “Profiles for ColorSync” and under Output/Printer your printer profile. Select the profile of the internal system colour space under “Internal”. *SilverFast* assumes your image application supports complete colour management . Please check for this feature in the manual of your software manufacturer.



### CMYK-Output with Colour Management (CMS Separation)

You have selected a CMYK colour space under “Photoshop / CMYK setup”. For this you should have an ICC profile you can select later in *SilverFast*. If not, you can save the settings with “save” into the System profile folder.

Now bring up *SilverFast* (from the “Import” menu).


Under “Options...” go to “CMS” in the *SilverFast* main dialogue. Under the section “Colour management” select ④ “ColorSync” under Internal-> Monitor and ⑤ “ColorSync” under Internal --> Output.

Under Scanner-> Internal in our example it is again ⑦ <NONE>. In the section “Profiles for ColorSync” select the same CMYK profile under – Output/Printer, which you have allocated in Photoshop. Under Internal, select the profile of the internal system colour space.


## How to save Profiles from Photoshop 5.02

Go to “File”, Colour Settings: RGB Setup. In this dialogue you can prepare your own settings and “Save...” them. Make sure, the profile goes into the right folder, so the System and *SilverFast* can access (load) it.

The path to save it into using **MacOS 9** is «.:System folder: ColorSync Profiles» and to save the file into.




The path to save it into using **MacOSX** is: «...: user : *user-identification* : Library : Color-Sync : Profiles ...».



The path to save it into using **Win98** is:

«C:/Windows/System/Colors»

Note: Profiles in *SilverFast* have a different name from the file name!





The path to save it into using **Windows 2000** is:

«C:/WinNT/System32/Color»

or

«C:/WinNT/System32/Spool/Drivers/Color»





The path to save it into using **Windows XP** is:

«C:/Windows/System32/Color»

or

«C:/Windows/System32/Spool/Drivers/Color»



### Attention!


Under Windows profile descriptions do not correspond to profile name. To make sure you do not involuntarily select profiles you do not want, move those profiles temporarily out of the Windows / System Colour directly into a new directory (folder).

### Example Settings SilverFast / Photoshop 6

In ADOBE Photoshop 6 all colour settings have been integrated into one menu under “Colour Settings”. It seems more complicated on first look but has become clearer structured in reality.

Once set up, you can save all as one setting and if required exchange with other settings.

Please carefully read the corresponding pages in your Photoshop manual.




## Example Settings SilverFast / Photoshop 7

In ADOBE Photoshop 7 all colour settings have been integrated into one menu under “Colour Settings”. It seems more complicated on first look but has become clearer structured in reality.

No changes were made to Photoshop 6. The same presets may be used.

Once set up, you can save all as one setting and if required exchange with other settings.

Please carefully read the corresponding pages in your Photoshop manual.



## 7.2 Calibration of your Scanner using SilverFast IT8 Calibration

IT8 calibration button, will open the IT8 dialogue.



IT8 button coloured = calibration is active.



IT8 button grey = calibration is disabled.



The IT8 button is NOT visible when this function is not activated in the software!

**SilverFastAi** for some high-end devices features a professional tool for calibration and generation of input ICC profiles. The calibration can be made for reflective and transparency positive originals. The calibration is NOT applicable to negative originals.

The IT8 calibration is an additional function in the **SilverFast** software. It is usually an option to the software and therefore has to be activated separately. In certain **SilverFast** versions - for selected scanners - this function is active by default. In cases where this function must be activated separately, a second CD Rom is required for this procedure - the "**SilverFast** Feature-CD". The separate activation procedure is described in chapter "SilverFast Feature-CD".

**SilverFast** has made the process of IT8 calibration very convenient – all steps are performed automatically by the software, just follow the instructions outlined below.



### 1. Position the IT8 Reference Chart on your Scanner Bed.


Make sure that the original is positioned inside the scan area of the scan bed. Avoid positioning on areas at the rim of the scanner bed, with some scanners this areas must be kept clear for hardware calibration. The orientation of the IT8 target should be as shown on the left.



### 2. Click "Prescan" (the Scanner performs a Prescan).



### 3. Click the button "Calibration"





### 4. The Window "IT8 Calibration" pops up

The preview window and the grid will open.



By clicking into the IT8 image of the dialogue window, the grid is reset to its standard position.

Position the grid in such a way, that all edges are precisely covering the IT8 target.



## 5. Start the Calibration

If the frame is correctly set up, the calibration can commence by clicking the “Start” button.

**SilverFast** will now search for the respective reference file for the chosen IT8 target.

## 6. Identifying the IT8 target and Searching for the Correct Reference Data File.

### 6a. **SilverFast** Locates the Reference Data File on Its Own


This usually happens very quickly and runs automatically; the IT8 target is identified by the barcode on its front. **SilverFast** then searches for the respective reference data file, and then launches the calibration.



For calibration in reflective mode, please make sure to select the corresponding reference file for reflective targets. The same applies for transparency calibration accordingly.

Confirm your choice with a click on the “Open” button.

## 7. Saving the ICC Profile



After the calibration has been completed you will get the message “Calibration has been successful”.

You’ll then have the option to save the result of the calibration as an ICC profile for system-wide colour management. Name and location of the profile can be selected by the user.


Close the dialogue window by clicking “OK”. A new prescan will be launched simultaneously to update the preview.

If the name of the profile just exists you are asked for replacing the just existing older profile.



## 8. Calibration is now Active.

The IT8 calibration button is now coloured and not longer grey.



### Attention!

Options...

For a subsequent activation of the calibration, please choose the following colour management settings:

Choose the option “ColorSync” (Windows “ICM”) in the “Scanner-> internal” menu.

After this, choose the correct calibration profiles for both transparent and reflective images.

After clicking the “OK” box of the CMS dialogue, the IT8 calibration is activated.

## Differences in Calibration Between a Scanner and a Digital Camera

When calibrating a digital camera, several factors have to be taken into account.

The great advantage of scanners is that they work with almost constant conditions: it has an almost constant light source, a fixed colour temperature and a constant distance between the object and the sensor, as well as an absolute array between object and sensor.


This is completely different with digital cameras! Nothing is really constant or standardised, leaving the camera much more flexible and therewith hard to calculate.

An IT8 calibration can be performed but, strictly speaking, lasts only as long as no changes are made to the surrounding factors.

These conditions are generally only found in photo studios, tabletop or during repro photography. They are strongly variable when working with changing light conditions, outdoor photography, etc. Each deviation of the factors makes the calibration work for only one single photo. If a light source is moved in a photo studio, a new calibration-photo is to be made. In order to do this, simply place a suitable IT8 target on a prepared stand into the photo to be taken, and capture the IT8 target in the photo. Then remove the target from the set, and re-shoot the photograph. By this method, two photos are taken, first one for calibration and after that the actual photograph. Professionals know the procedure with grey card tests – the objective is the same with the steps described here.

## Sequence of IT8 calibration

A summarized run through the calibration process in the **SilverFast** software.



1. Place the IT8 target into scanner and align the target
2. Initiate a prescan
3. Click once on IT8 calibration button (a dialogue opens).
4. In preview window, position the grid exactly over the IT8 target
5. Click once on “Start” button  
(if a dialogue opens: browse to location of corresponding IT8 reference file and select it. Confirm selection by clicking the “Open” button.)
6. The IT8 calibration process itself runs automatically.  
The IT8 dialogue window informs you about the progress of the calibration process.
7. Save the result of the calibration as ICC profile for system-wide colour management.
8. The IT8 calibration process is completed and automatically set active.


## Examples Where to Find the Production Charge Number on IT8 Targets of Different Manufacturers.



**LaserSoft Imaging target**  
35mm, transparent,  
charge number is on slide mount.



**LaserSoft Imaging target**  
4x5 inch, transparent,  
sticker on the protective sleeve.




**LaserSoft Imaging target**  
5x7 inch, reflective,  
written directly on the target  
- bottom right.




**Kodak target**  
35mm, transparent,  
reference is date printed directly  
on the target and also on the slide  
mount.

**LaserSoft Imaging target**  
DIN A4, reflective,  
printed directly on the target  
- bottom right.



**C-ROES target**  
35mm, transparent,  
reference is date printed directly on  
the target

**C-ROES target**  
DIN A4, reflective,  
printed directly on the target  
- bottom left.





*Non-calibrated Scan*




*Calibrated Scan (IT8 Calibration)*



*Chapter 7.3*

*Addendum*



## 7.3 Addendum

The following chapter introduces into basic scanning concepts and why a good scanner usually has more than 8 bits per colour.

<b>7.3 Addendum</b>	<b>437-454</b>
Scan concept	
439 Scan resolution	440
Need for more than 256 levels of grey	441
Screening	442
Calculating the scan resolution	443
Which „resolution“ does <b>SilverFast</b> indicate?	444-445
Optimizing scanner resolution for inkjet printers	446-447
Selective colour correction	448
Colour model relations	449
Keyboard shortcuts Mac and PC	450-454
<b>7.4 Index</b>	<b>455-470</b>
<b>7.5 Glossary</b>	<b>471-491</b>

## Scanning Concepts

What is a brilliant image? Do I really need very high resolution?  
What is interpolated resolution?

Imaging has been an abstract science which was practised by well trained professionals. Now with the advent of low price PCs, scanners, printers and digital cameras imaging has become a mass phenomenon.

It is exciting to see how this technology is impacting and changing economy and society. It seems that in an information society imaging is becoming the premier tool to convey ideas and compact messages.

This recognition emphasises the importance to learn more and become familiar with the basic imaging concepts. It will help you to realise your visions and ideas much more quickly!

So for your own advantage do study the following pages carefully!

## Scan resolution (dpi)

Some important definitions are clarified here. They form the vital basics of image reproduction theory.

### Input Resolution

Resolution is a common expression that refers to the number of finest elements of an image or pixels (pixel is an artificial word made of picture and element), which a sensor, for instance a scanner, can record or distinguish. The unit of measure is in general „dpi“ = dots per inch or „dpcm“ = dots per cm. The higher the resolution, the greater the number of pixels can be scanned.


### Optical Resolution / Interpolated Resolution

The optical resolution is also called physical resolution. It defines how many lines or points per inch or cm the CCD and optics of the scanner can clearly distinguish. This can be seen when two lines, being very close to each other, can still be seen as two different lines and not as one.


Interpolated resolution is mathematical resolution which, as we will see later, is only important for line art scans, not for greyscale scans. It is calculated via hardware or software.

### Greyscale


Greyscales are of very high importance for scanning technology because, in order to reproduce a greyscale image, the scanner has to sense every single image point with a certain depth of data in order to reproduce the different levels of grey correctly. A good scanner should be sufficient to distinguish 256 levels of grey (8 bit), but as we will see on the next page, this is not enough. The scanner should distinguish more than 256 levels of grey internally.




1. Histogram without spreading in Photoshop



2. Histogram with spreading in Photoshop



3. Histogram in SilverFast with automatic optimisation



4. Histogram after scan with SilverFast and 10 bit

## Need for More than 256 Levels of Grey

Images are rarely ideal. Furthermore, the scanner itself can deviate (in itself) while scanning images. Adjusting the highlight–shadow values of an image on a prescan lets a scanner with an internal 10- to 8-bit transformation expand the reduced tonal range (fig. 1) to a full range of 256 levels of grey. By expanding a reduced tonal range with only 8-bit transformation, gaps in the tonal scale are produced where grey values are missing. Detail and sharpness of the image are lost or reduced. This can also happen when the transformation-algorithm from 10- to 8-bits is not optimised. The gaps in the histogram (fig. 2) also called spikes, become clearly visible.

Through an optimised transformation of the expansion of tonal values with 10- or 12-bits in *SilverFast*, the end result, that is to say, the final scan displays a gapless distribution of grey levels across the entire greyscale (see fig. 4).

The correct adjustment of highlight and shadow, for instance which values on the prescan become white and which become black, has a strong influence on the quality of a reproduction. *SilverFast* helps locate the brightest and darkest points in two ways: First, the densitometer can be set to CMY% and, by moving across the prescan, indicates where the brightest and darkest points are. Second, the highlight / shadow tool displays the brightest point when the “Ctrl” key is pressed, and the darkest when the “Alt” key is pressed (together with the “Command” key on Mac and the “Alt” key on PC, respectively). For displaying the brightest and the darkest point of the image on the prescan in combination with the highlight/shadow tool, click and hold the white or black square respectively.



Show brightest point



Show darkest point

Thus, the end points are easily set onto the correct spots in *SilverFast* (fig. 3).



Fig. 1



Fig. 2





Fig. 3



Fig. 4

## Screen Resolution (lpi)

In order to reproduce different shades of grey, the printing technology uses the screening technology. A dot matrix is the most economical way to produce shades of grey.



### Screening Matrix

*of an image point simulating grey through single image setter dots*

An image dot from the scanner is transformed into a screening matrix (in general a 16x16 Matrix). If a screening dot is black, up to 256 image-setter pixels can be set in a screening cell. In a screen of 152 lpi there are 152 screening dots in a line. The unit of measure lpi (lines per inch) is often confused with printer resolution. The unit of measure for printer resolution is generally dpi (In some countries, lpcm (lines per centimetre) is the unit of measure for the image setter's resolution as well as for the screening frequency). Once again the units of measure:

**Printer resolution:      dpi / dpcm    (lpcm)**

**Screening resolution:   lpi / lpcm**

The images on the left show the effects of different scanner and screening resolution. Image 1 shows a normal scan with 220 dpi printed on a laser printer with 120 lpi. Image 2 shows an enlargement of a selection. Image 3 shows a scan with very low resolution (under 72 dpi) printed with 120 lpi. Image 4 shows a scan from image 2 printed with a line screen of only 20 lpi.



### **High scan resolution**

*High scan resolution is important only in line art scans. It should be between 800 to 1000 dpi depending on the printer resolution.*

## **Calculating the Scan Resolution**

The best possible scanning resolution is very important and should be well thought out “the more the better” does not always hold true!

To Clarity:

Shades of greyscale images are converted into dots made of a 16x16 matrix when imaged on to an image setter. Ideally, a screening dot contains 256 individual pixels. When a photograph is scanned and printed onto a 150 line screen, each greyscale dot is converted into a 16x16 matrix. An image setter with a resolution of 2540 dpi is just capable of imaging such screening dots.

Since there are losses in the process of analog-digital conversion, an additional Q-factor (Q for Quality) is introduced. This factor is generally 1.4, and, with exception, 2.0.

As a result, the following formula for the calculation of the ideal scan resolution may be used:

$$\text{Scan resolution} = \text{output screen} \times 1.4 \times \text{scale-factor}$$

### **For Example:**

The scan resolution for a 150 line screen with a 1:1 scaling-factor has to be calculated.

$$\text{Scan resolution} = 150 \times 1.4 \times 1 = 210 \text{ dpi}$$

The resulting file size for an A4 page for black and white greyscale is 5.77 MB, for colour 17.3 MB.

300 dpi would roughly double the file size. This shows the importance of setting the optimal resolution since memory requirements and processing time increase dramatically.

### **Automatic Calculation of Optimal Scan Resolution in SilverFast.**

*The calculation of optimal scan resolution results in maximum quality, less memory load and faster processing. For this very reason the automatic calculation of optimal scan resolution was integrated into SilverFast. Having chosen the quality factor of 1.5, you only have to input the desired output line screen (150 line screen) and the required output size. SilverFast automatically sets the optimal scan resolution for you.*


For a 121 line screen for a newspaper and a scale-factor of 50% the calculation is as follows:

$$\text{Scan resolution} = 122 \times 1.4 \times 0.5 = 85 \text{ dpi}$$

If you want to double the image size :

$$\text{Scan resolution} = 122 \times 1.4 \times 2 = 341 \text{ dpi}$$

The images on the right show, what has been explained earlier: that higher image resolution is not significant for better image quality.



### Which “Resolution“ does *SilverFast* indicate?

In *SilverFastAi* you can monitor three different aspects of scan resolution:

a) **Output Resolution:** Will be continuously displayed. This represents the resolution, which the image will have after the scan, eg. in Photoshop. The value is derived from *SilverFast's* integrated formula, which relates quality factor and output-line screen.

b) **Optical Resolution:** Depressing “Ctrl“ key will display the optical resolution the scanner is using currently. Every Scanner can only use certain optical resolution increments, depending on the hardware. Eg. 300, 600, 1200 ppi, but not 249 ppi. *SilverFastAi* will always use the next higher hardware resolution, here 300 ppi, and will then interpolate down. This way the full quality is preserved. This way any loss in quality is eliminated .

c) **Interpolated Resolution:** To check whether the scanner does not interpolate “up“, you can depress the keys “Ctrl + Shift“. Now you can see the internally used, “calculated“ or “interpolated“ resolution. Here all values are possible such as 249 ppi from our example above.



Be alerted once the second value (with “Ctrl + Shift“) is higher than the first value (only with “Ctrl“). This indicates the scanner would interpolate “up“ and generate new pixels which are not present in the original image. Moderate interpolation up to 1.3 times max optical resolution puts you on the save side normally, depending on the quality of your scanner, of course.

Generally **SilverFast** inhibits “Misuse” by limiting the max resolution to a factor of 2 or 2.5.

*Images with Varying Resolution*



100 dpi



200 dpi



300 dpi



400 dpi

## Optimum Scan Resolution for Inkjet Printers

In order to print image scans with an inkjet printer without Post-Script and without simulation of offset screens, effectively a few points should be observed already before the scan.


 Please note: You should scan with reference to file size really needed, i.e. Scan size (file size) should ideally reflect the number of pixels needed for the print. Larger than necessary files only congest the computer system and do not lead to a better printing result! All necessary tools to get to ideal file size are built into **SilverFast**. There are no complex formulas and no conversions required.

In order to get optimum results it is recommended to do an initial test. With this test you will find the optimum resolution for the current printer (the printer connected), with relation to a special paper:



1. In the **SilverFast** main dialogue the “Quality factor is to be set” to 1.5 and “Scaling” is to be set to 100%.
2. The original to be scanned should be a contrasty slide with lots of details or a similar reflective halftone. do not use printed samples from magazines or books!
3. After the preview scan create a small scan frame (eg. 9x6cm) over an area with significant details.
4. The image will be optimized as usual: image auto-adjust, Gradation, colour correction. Under “Filter” the “Unsharp Masking”, if active should be switched off.
5. In the **SilverFast** main dialogue (“Frames” panel) under “Screen” input a value of 20 lpcm. In the same dialogue input “20 lpcm” as well as the file size as “Name” for this scan frame.
6. While depressing the “Alt” key and dragging the scan frame will be copied. Position the new scan frame exactly onto the same position as the first frame.



7



9



*Example of positioned test scans on a DIN A4 format sheet.*


7. For the new scan frame input “30 lpcm” under “Screen“. Then input “30 lpcm” for “name”.
8. Now repeat steps 6 to 7 for the values “40 lpcm” until “80 lpcm“, with steps of 10 in between.
9. In the main dialogue change to the “General“ panel and select “batch Mode (File)” under “Scan Mode“.
10. Start processing of the seven scan frames with clicking on “Scan Batch“. A dialogue will come up asking you for a destination for the final scans.
11. When the seven scans are done, mount them in a layout-program onto one paper, e.g. letter format. It is important that all scans get exactly the same frame size! Mark each scan frame with the full name of the image file respectively!
12. The test chart can now be printed and evaluated.
13. Evaluation of results:
  - Which image, resp. which “screen“, will get the best result with the current paper ?
  - Where can you distinguish fine resolution just about?
  - What is the optimum screen? Notice how rapidly file size increases with higher line screens!
  - In reality the limit for recognizing any enhancement in print quality will be between 40 to 50.
  - It will be interesting to see the comparison print of the same image file on different paper or other printers.

## Selective Colour Correction

### Colour in Colour Correction




Selective colour correction was developed for high-end scanners, and consists of changing colours within a colour. The colours red, green, blue, cyan, magenta and yellow are corrected. The cast colour can be reduced and the current colour can be increased. The cast colour of red is cyan, of green is magenta, of blue is yellow.



The diagram above shows the relationship between colours. The primary colours red, green, and blue have opposite colours as their complementary colours. The neutral tones between black and white lie on a grey axis.

### Colour Model Relations

The following model shows the relation between primary colours and contaminating colours (complementary colours). In the selective colour correction these colours can be increased or decreased.



### Contaminating Colours

Contaminating colours are those which lead to a “dirtying” also referred to as a “blackening”. The colours lose their brilliance and tend to grey. The following table shows the relations:

<b>Colour</b>	<b>→</b>	<b>Contaminating colour</b>
Red	→	Cyan
Green	→	Magenta
Blue	→	Yellow
Cyan	→	Magenta / Yellow
Magenta	→	Cyan / Yellow
Yellow	→	Magenta / Cyan

## Keystrokes in *SilverFast*

Action	Macintosh	Windows
<b>Description of keyboard shortcuts and their respective counterparts</b>		
Command.....	Command-/Apple-Key .....	-
Alt.....	Opion-/Alt-Key .....	Alt-Key
Shift .....	Shift-Key .....	Shift-Key
Ctrl.....	Control-/Ctrl-Key .....	Control-/Ctrl-Key
Return .....	Return-/Enter-Key .....	Return-/Enter-Key
Esc.....	Escape-/Esc-Key .....	Escape-/Esc-Key

### *ScanPilot / ImagePilot*

Apply / Execute current tool .....	Return .....	Return
Scroll / Next action .....	Up and Down arrow .....	Up and Down arrow

### Prescan, scan / Preview, process

Stop prescan / stop scan.....	Command+Period.....	Strg+Period
Switch to other colour space.....	Ctrl+Click on.....	Right mouse button+Click on
	Scan-/Process-button .....	Scan-/Process-button
Zoom	Ctrl+Click&Drag .....	Ctrl+Click&Drag

### Image frames

Duplicate frame .....	Alt+Click&Drag.....	Alt+Click&Drag
Entire Window in one frame .....	Command+A .....	Ctrl+A
Delete frame (extended keyboard).....	Delete .....	Delete
Delete frame (normal keyboard).....	Alt+Backspace.....	Delete
Frame reset .....	Reset-button.....	Reset-button
Copy settings of one frame .....	Alt+Click on active frame, .....	Alt+Click into inactive
into an other frame	click then into target frame ..	target frame

## Action

## Macintosh

## Windows

### Auto-adjust

Resetting auto-adjust . . . . . Alt+click on . . . . . Alt+Click on  
Auto-adjust button . . . . . Auto-adjust button

### Highlight / shadow / midtone tool (HSM-tool)

Set highlight . . . . . Click on white triangle of HSM-tool  
Set midtone . . . . . Click on pipette of HSM-tool  
Set shadow . . . . . Click on black triangle of HSM-tool

### Multiple attempts with pipette

Hold down pipette for multiple . . . . . hold down Alt . . . . . hold down Alt  
attempts (only highlight, shadow)  
Reset highlight / shadow . . . . . Alt+Pipette of HSM-tool  
Display brightest point . . . . .  Click on white square . . . . . F6  
Display darkest point . . . . .  Click on black square . . . . . F5

### Histogram

Show result histogram . . . . . Alt in the histogram dialogue. Alt in the histogram dialogue

### Selective colour correction

Select all colours . . . . . Command+A . . . . . Ctrl+A  
Select additional colour . . . . . Shift+Click into prescan . . . . . Shift+Click into prescan  
Select additional colour column . . . . . Shift+Click on LED . . . . . Shift+Click on LED  
below column . . . . . below column  
Show inactive mask area . . . . . F7 . . . . . F7  
(dialogue must be closed)

### Reset

Reset all parameters . . . . . Shift+Click on Reset-button . . . . . Shift+Click on Reset-button  
Frame reset . . . . . Alt+Click on Reset-button . . . . . Alt+Click on Reset-button  
Undo/Redo last operation . . . . . Command+Z . . . . . Ctrl+Z

Action	Macintosh	Windows
<b>Opening a dialogue window</b>		
Zoom in preview . . . . .	Command+1 . . . . .	Ctrl+Alt+1
Image auto-adjust . . . . .	Command+2 . . . . .	Ctrl+Alt+2
Histogram dialogue . . . . .	Command+3 . . . . .	Ctrl+Alt+3
Gradation dialogue . . . . .	Command+4 . . . . .	Ctrl+Alt+4
Global colour correction . . . . .	Command+5 . . . . .	Ctrl+Alt+5
Selective colour correction . . . . .	Command+6 . . . . .	Ctrl+Alt+6
Expert dialogue . . . . .	Command+8 . . . . .	Ctrl+Alt+7
Leave dialogue/Leave SilverFast . . . . .	ESC or Command+Period . . . . .	ESC or Ctrl+Period
Start scan / Process image . . . . .	Return/Enter . . . . .	Return/Enter

### Main dialogue

Undo/Redo last action . . . . .	Command+Z . . . . .	Ctrl+Z
Show current hardware resolution . . . . .	Ctrl . . . . .	F5
Show calculated scan resolution . . . . .	Ctrl+Shift . . . . .	F6

### Masks in SilverFastSRD

Hide mask frame . . . . .	Ctrl . . . . .	Ctrl
Shade inactive mask area . . . . .	Alt+Ctrl . . . . .	Alt+Ctrl
Reduce mask . . . . .	Alt . . . . .	Alt
Extend mask . . . . .	Shift . . . . .	Shift

### JobManager

Select all job entries . . . . .	Command+A . . . . .	Ctrl+A
----------------------------------	---------------------	--------

**Action****Macintosh****Windows*****VL* (virtual light table)**

Context menu in album and overview ..	Ctrl+Click .....	Right mouse
Preview mode, full screen, .....	Command+Shift+F .....	Ctrl+Shift+F
fit to screen		
Display EXIF infos .....	Command+I .....	Ctrl+I
Album, mark all images .....	Command+A .....	Ctrl+A
Album, delete image.....	Command+backspace.....	Ctrl+backspace

***EP* (extended printing dialogue)**

Crop opposing edges / corners .....	Shift+Click&Drag .....	Shift+Click&Dra simultaneously
-------------------------------------	------------------------	-----------------------------------

***SilverFast Launcher***

Terminate .....	Command+Q .....	Ctrl+Q
-----------------	-----------------	--------





*Chapter 7.4*

*Index*

## 7.4 Index

### Symbols

%lt 274  
%lx 274  
%nW 274  
%oN 274  
± 3 f-stops 220  
1:1 copy function 406  
12 colour sectors 158  
16 bit HDR grey scale 72  
1 bit 215  
24 bit 72  
256 levels of grey 445  
3/4 tone 156  
35 mm slides 67  
3x3 pixels 53  
48 bit 72, 425  
48 bit HDR colour 72, 339  
6 colour sectors 158  
6x4.5 43  
6x6 43  
6x7 43  
6x9 43  
90° steps 47, 303

### A

a/b channel 293  
AACO (Auto-Adaptive Contrast Optimization).  
See SilverFastAACO  
ACR = Adaptive Colour Restoration. See Silver-  
FastACR  
Activate a scan frame 89

Active scan frame 39  
Activity indicator 46  
ADF / Document feeder 70, 237, 238  
Adjust Images automatically 340  
Administrator 28  
Adobe RGB 416  
Advanced colour cast removal. See MidPip4  
Album folder 66, 259  
Album palette 265, 267  
Album window 278  
Anti-Aliased 54  
Appearance manager 19  
Apple RGB 416  
Apply 93  
APS film 41, 235, 236, 237  
    APS film feeder 42  
    APS overview 235  
    Index scan 235  
ASA/ISO value 221  
Aspect ratio 78  
Auto-adjust 108, 114, 137, 138, 220  
    Auto-adjust and colour cast preservation 118  
    Auto-adjust and colour cast removal 117  
    Auto-adjust and threshold 119  
    Auto-adjust reset 118  
    Auto threshold highlight 121  
    Auto threshold shadow 121  
    Colour of auto-adjust button 114  
Auto-focus 250  
Auto-gradation 108  
Auto-threshold for highlights and shadows 59  
Auto contrast 61  
Automatic density 40  
Automatic document feeders (ADF) 237

Automatic orientation detection 67  
Automatic prescan 94  
Automatic when ADF 61  
Automatic with ADF 238  
Auto palette 59  
Auto pipette middle factor 60  
Auto sharpen 199

## B

b/w film 232  
Barcode 435  
Baseline optimised 245  
Batch mode 70, 87, 238

- Batch scan 86
- Interruption of a batch 238
- Setting of an image number in the batch 244

Batch mode (File) 87, 238  
Batch scans 87  
Black and White negatives or slides 394  
Black and white point 42  
Blind colour 65  
Blue dot 277, 287  
Bright contour 204  
Brightest point 59, 131

- Displaying Brightest and darkest point of an image 131

Brightness 149, 293  
Browser 266  
Brush 167, 382

## C

C41 process 394  
Cache 259, 260, 263, 278

Cache size 66  
Deleting the cache memory 285  
Green arrow 263  
Red square 263  
Calibration of your scanner 433  
Calibration profile 64  
Camera Storage Media 271  
CCD 217  
CCD noise 42  
Chapter 1: Installation 17  
Chapter 2: Overview 35  
Chapter 3: Presets 49  
Chapter 4: Prescan Design 81  
Chapter 5: Tools 105  
Chapter 6: Special Functions 191  
Chapter 7: Colour Management 411  
Choose plug-in folder 30  
Clone tool 44, 401

- Auto texture 403

cm 52  
CM12 175  
CM6 175  
CMS (Colour Management System). See Colour management

- CMS dialogue 417

CMS palette 62, 93, 417

- Colour management 417, 418
  - Internal -> Monitor 418
  - Internal ->Output 419
  - Scanner -> Internal 418
- Embedded ICC profiles 417, 425
- Plug&Play CMYK 417, 426
  - CMYK Output with Colour Management 427
  - Scanning with Colour Separation 426
- Profiles for ColorSync (ICM) 417, 420
  - Internal 421

- Output/Printer 422
  - Rendering Intent 423
  - Scanner (Reflective) 420
  - Scanner (Transparency) 420
  - CMYK colour simulation** 91, 427
  - CMYK output** 427
  - CMYK Values Visible on the Prescan** 195
  - ColorSync** 62, 114, 262, 416, 425
  - Colour balance** 108, 155, 156, 157
    - Resetting colour balance 156
  - Colour cast** 130, 137, 138, 230, 231, 292
    - Automatic colour cast removal 137
    - Colour cast preservation 118
    - Colour cast removal 59, 117
    - Manual colour cast removal 138
    - Preserving a colour cast 130
  - Colour channel in histogram** 136
  - Colour circle** 160, 164
  - Colour filter (blind colour)** 65
  - Colour in colour correction.** *See auch* Selective colour correction
  - Colour management** 413
    - Comparing the colour spaces 416
    - Introduction 413
    - Objective of Colour Management System 413
    - Objective of the SilverFast Colour Management 414
  - Colour matrix 12** 158
  - Colour matrix 6** 158
  - Colour model relations** 453
  - Colour models** 194
    - CMY 194
    - CMYK 194
    - Colour model RGB or CMY 53
    - HSL 194
    - K 194
  - LAB** 194
  - LCH** 194
  - RGB** 194
  - Colour negatives** 394
  - Colour separation** 426
  - Colour space compression** 143
  - Colour temperature** 292
  - Colour tint** 261, 292
  - Colour to Grey Conversion** 180
  - Complementary colours** 452, 453
  - Compression of colour Space** 141
    - Example for colour space compression 143
  - Concept of optimising images** 112
  - Contact sheet** 270, 282
  - Contaminating colours** 453
  - Context menu** 195
  - Contrast** 149, 293
  - Copy a scan frame** 90
  - Copyright** 3
  - Credits button** 32
  - Curve points** 151
    - Control of the curve points 152
- ## D
- Dark contour** 203, 204
  - Darkest point** 131
    - Displaying darkest point 132
  - DCPro.** *See* SilverFastDC...
  - DCProStudio.** *See* SilverFastDC...
  - DCS file format** 243, 245
    - Multi file 245
    - Single file 245
  - DCVLT.** *See* SilverFastDC...
  - Default dialogue.** *See* Options... dialogue

- Defaults.** See Options... dialogue
    - Standard defaults 59
  - Default setting** 54
  - Delete a scan frame** 89
  - Delete cache / Delete images** 285
  - Delete frame** 42
  - Deleting Images** 285
  - Densitometer** 101, 123, 134, 145, 186, 194
    - Before and after values 194
    - Densitometer is displayed in the gradation and the selective colour correction dialogue 194
    - Densitometer palette 39, 91
    - Densitometer radius 53
    - Densitometer reading and gradation curves 186
    - Displaying the densitometer measure points with the histogram and gradations dialogues 145
    - Multiple densitometer 145
    - Selecting the colour space in the densitometer 146
    - Switching the densitometer 195
    - Transfer of the brightest/darkest point to the multiple densitometer 146
  - Descreening** 205, 207
    - Automatic descreening 205, 206
    - Automatic descreening (intensive) 205, 206
    - Before-After view 207
    - Moiré 205, 208
    - Preview button 207
    - USM & Descreening 205, 209
  - Device** 69
  - Dialogue overview** 39
  - Dialogue window** 37
    - Macintosh 37
    - Windows 38
  - Difference between ScanPilot and ImagePilot** 110
  - DIGITAL ICE technologies** 41, 232, 371, 375
  - Displaying a processed image** 56
  - Document feeder** 103, 238
  - Dot screen** 76
  - dpcm** 446
  - dpi** 446
  - Drag & drop** 80, 279
  - Dust- and scratch removal.** See SilverFastSRD
  - Dust and scratch removal** 41
- ## E
- E6 process** 394
  - Eject button** 41
  - Embed ICC profiles** 64
  - Embed profiles** 64
  - Enhanced print dialogue.** See PrinTao
  - Evening** 74
  - EXIF** 266, 268, 277, 284, 298, 314. See SilverFastDC...
  - Expert dialogue** 108, 187
    - Equal parameters for a row 187
    - Exporting the image parameters as a text file 189
    - Fourth column for grey values 188
    - SF Statistic.txt 189
    - Showing / Hiding the curve window Dialogue 188
  - Expert mode** 274, 386
  - Export Album** 271
  - Export images** 287
  - Exposure** 66, 292
  - Extended print dialogue.** See PrinTao
- ## F
- Feature CD** 32
  - File browser** 299, 300
  - File format** 87, 241, 243, 247, 353

- Reading different file formats 247
- Saving different file formats 241
- File name** 39, 76, 354
- File size** 76
- Film holder** 43, 235, 237
  - APS adapter 235
  - Automatic document feeders (ADF) 237
  - Batch scans 237
  - Eject 236
  - Film Strip Holder 236
  - Holder transport 43
  - Middle formats 43, 237
  - Panorama formats 43, 237
- Film scanner** 239, 347, 357, 358
  - Film scanners with a magazine 239
    - Area 240
    - Holder transport 239
    - Overview dialogue 240
  - JobManager 347
  - SilverFastJobManager workflow with film scanners 357
- Film strip holder**
  - Adjusting the Film Strip Position 237
- Film strip position** 42, 237
- Filter** 39, 73, 199
  - Descreening 73
  - GANE 73, 211
  - USM 73, 199
- FireWire** 21, 80
- Fixing width and height** 76
- Flash cards** 271
- Flip** 47, 282
- Focus** 41, 249
  - Auto-Focus 250
  - Focus preview 251
  - Focussing the Scanner 249

- Focus switch 249
- Manual Focus 250
- Manual focus with preview 251
- FOGRA** 298
- Frame deletion** 42
- Frame Inset** 61
- Frame number** 86, 94
  - Frame number indicator 42
- Frame palette** 39
- Frame sets** 70
- Frames on Prescan** 85
- Full screen preview** 66

## G

- Gamma gradation** 55
  - Gamma Gradation for HDR Output 55
  - Gamut Expected in 48bit/HDR 55
- Gamut** 196
  - Gamut Warning 196
- GANE (Grain- and Noise Elimination)** 211
  - Activating GANE 212
  - Before-After preview 211
  - Expert Mode 213
  - Intensity 213
  - Threshold 213
- General palette** 39, 69
- Global colour correction** 108, 155
- Gold tones** 74
- Gradation** 108, 147, 155
  - Adjusting gradation curves 149
    - By entering values into the input fields 149
    - By loading saved gradation curves 149
    - By moving the curve points 149
    - By using the sliders 149
  - Colour channels 150

- Comparison of the different gradation dialogues 111
- Deactivating gradation curve points 151
- Deleting a gradation curve 150
- Extended gradation curves 153
- Gradation curves 147
- Hottrack gradation 152
- Loading Photoshop gradation curves 153
- Range selection 156
- Reset 156
- Resetting deactivated curve points 151
- Saving a gradation curve 150
- Selecting gradation curves 153
- Grain- and Noise Removal** 211
- Green dot** 277
- Greyscale** 444, 447
- Grid frames** 326

## H

- H-S cast** 74
- Halftoning** 65
- HDR.** See SilverFastHDR...
- Help button** 40
- Help lines** 326
- Highlight** 108, 149
  - Preserving specular highlights 130
  - Setting highlight 123
  - Specular highlights 130
- Highlight / Shadow tool** 123, 132
  - Highlight / Shadow reset 124
  - Highlight / Shadow with offset 123
  - Preserving a colour cast with the highlight / shadow tool 130
- Highlight and shadow offset** 129
- Highlight Cast** 74

- Highlight Offset (Brightest Point)** 59
- Highlights** 141
- Highlight triangle** 121
- High resolution prescan** 54, 97, 100, 184
- HiRePP (High Resolution Picture Performance).** See SilverFastHiRePP
- Histogram** 108, 133, 141
  - Channel selection 136
  - Compressing colour space via histogram 144
  - Compression of colour space in histogram 141
  - Histogram-Dialogue in SilverFast...SE versions 133
  - Optimising a histogram manually 139
  - Three-part histogram 135
    - Staggered three-part presentation 136
    - Standard mode 135
    - Three-part parallel presentation 135
- Horizontal scaling** 76
- Hottrack gradation** 152
- HSL** 228
- HSL controls** 159
  - HSL Correction by Sliders 161
- Hue** 160, 161, 228

## I

- ICC printer profile** 405
- ICC profile** 114, 195, 262, 299, 414, 425
  - Camera specific ICC profile 262
  - ColorSync 262
  - Generate an ICC camera profile 262
  - ICM 262
- ICE** 232, 371, 375. See DIGITAL ICE technologies
- ICM** 62, 114, 262, 416, 425
- Image auto-adjust** 108, 114

- Image compression 245
- Image mode 71
- Image number 244
- Image orientation monitor 47
- Image overview 348
- Image overview dialogue 42
- ImagePilot 40, 110
  - Prefs button 110
- Image settings 409
- Image settings dialogue 292
  - Brightness (mid-tones) 293
  - Colour 292
  - Colour-distortion reduction 293
  - Contrast 293
  - Exposure 292
  - Light source 292
  - Pipette 292
  - Realtime Histogram 293
  - Saturation 293
  - Settings 293
  - Smoothing of luminance 293
  - White balance 292
- Image type 74
  - Image type presets 39
- Import 28
- Improving the sharpness of artwork 199
- inch 52
- Index 355
- Index scan 42, 235, 348
- Info button 40
- Input > Internal 62
- Input dimensions 39
- Installation 17, 18
  - Installing SilverFast Plug-in 22
  - SilverFast as a TWAIN Module 25
- Internal > Monitor 62
- Internal > Output 62
- Interpolation of scan resolution 54
- IPTC 266, 271, 272, 274, 283, 298, 314.
  - See SilverFastDC...
    - Load 283
    - Save 283
- iSRD 369, 371. See SilverFastiSRD
- iSRD (dust and scratch removal with infrared technology). See SilverFastiSRD
- IT8 calibration 42, 222, 253, 262, 336, 433
  - Barcode 435
  - Coloured IT8 button 433
  - Differences in calibration between a Scanner and a digital camera 437
  - Grey IT8 button 433
  - IT8 calibration with SilverFastDCPro 336
  - IT8 reference folder 435
  - IT8 target 337, 433
    - Charge number of IT8 targets 439
    - Identifying the IT8 target 434
    - KODAK IT8 targets 435
    - Reference data file 434
  - Reference data file 434
    - Reference data file not found 435
  - Steps of a calibration with SilverFastDCPro 337

**J**

- JM (JobManager).** See SilverFastJobManager
- Job** 344
- JobManager** 340, 343. See SilverFastJobManager
- JPEG 2000 file format** 246
- JPEG file format** 245
  - Format 245

Quality 245  
JPF 246

## K

Keep original resolution 340  
Keep output height or width 78  
Keep the ratio of height and width 78  
Keystrokes in SilverFast 454  
Kodachrome film 232

## L

L (logarithmic) 154  
Lamp brightness 66  
Landscape 74  
Lasso 167, 382  
Layers 159, 175, 383

- Adding layers 176
- Delete 177
- Moving layers 178
- Stapling order 178
- Switch 177

Less auto sharpen 199  
Levels 122  
License 4  
Light contour 203  
Light source 292  
Limit gamma slope 66  
Linear midtone 154  
Line art scans 215

- Threshold 216
- Zooming for optimum threshold definition 216

Lock 39, 77, 79  
Logarithmic midtone 154  
lpcm 446

lpi 446  
Luminance 160, 161, 228, 293

## M

Macintosh 19  
Mac OS 9.2 19  
Magazine (for slides) 239  
Magnifier 97, 277. See Zoom  
Manual focus 250  
Mask edge size 57, 169, 175  
Masks 57, 159, 167, 175, 382, 397

- Changing a Mask 170
- Delete 172
- Inverted mask 383
- Move 171
- New mask 167
- No mask 171

Matrix 200  
Maximum cache size 66  
Measurement units 39  
Meta data 311, 314  
Middle format 43  
Middle formats 237  
MidPip4 126, 145

- Adjusting neutral values to a determined density 128
- Alert messages 128
- Delete neutral points 128
- Editing the MipPip 127

Midtone 108, 141, 149, 154, 156

- Linear and Logarithmic Midtone 154
- Setting midtone 125

Minimize window 39  
Mirroring 40

- Flip 47

**Moiré** 205  
**More auto sharpen** 199  
**Moving of a scan frame** 90  
**Multiple densitometer** 134, 196  
    **Transfer of the brightest/darkest point to the multiple densitometer** 197  
**Multiple FixPip** 101, 134, 186, 196  
**Multiple Frames** 85  
**Multiple neutralising pipette.** See MidPip4  
**Multiple sampling** 42, 217  
    **Multi-Sampling with Auto-Alignment** 217  
**Multiple scan frames** 85  
**Multiple scanning** 42  
**Multiple slide scanner settings** 239

## N

**N (normal)** 154  
**Naming of scan frame** 242, 243  
**Navigation window** 266  
**Navigator** 299, 300  
**Navigator palette** 97  
**Neg.Direct** 70  
**NegaFix** 219. See SilverFastSC2G  
    **Auto tolerance** 219, 224  
    **Components** 234  
    **Expert dialogue** 219, 223  
        Automatic mask 226  
        Changing the film gradation curves 229  
        Curves menu 224, 229  
        Expansion Menu 224  
        Expansion menu in detail 226  
        HS and L dialogue 225  
        HSL colour space 228  
        Magnifier 224, 229  
        Neutralizing colour casts 230  
        Producing a colour cast deliberately 231

    Reset 227  
    RGB-CMY switch 227  
    Save 227  
    Save the newly created profile 225  
    Saving changes as a new profile 231  
    Set neutral grey 225  
    Setting orange mask highlight shadow points 228  
    Smoother 229  
**Exposure** 219  
**Film speed** 219  
**Film type** 219  
**Importing film profiles** 223  
**Manufacturer** 219  
**Negative.** See SilverFastNegaFix  
**Neutral point** 126  
    **Deleting neutral points** 128  
**Neutral values** 126  
**Night** 74  
**Noise** 217  
**Non-PostScript-Printer** 422

## O

**Offset** 129  
**Open button** 255, 335  
**Open VLT at start up** 56  
**Options... dialogue** 53  
    **Auto Defaults** 59  
    **CMS (colour management) settings** 62  
    **General Defaults** 53  
    **Special Defaults** 65  
**Options parameter** 54  
**Orientation of the image** 47  
    **Orientation window** 47  
**Original** 70, 103, 238  
**Original height** 76

**Original width** 76

**Output dimensions** 39

**Output file size** 39

**Output height** 76

**Output screen** 39

**Output width** 76

## P

**P&P CMYK** 62, 91, 417, 419, 425, 427

Softproof 91

**Panorama captures** 43, 237

**Permanent Softproof** 195

**Permanent softproof** 91, 427

**Photoshop 5.02** 428

**Photoshop plug-in** 22

Launching and activating SilverFast via Photoshop  
28

**Pica** 52

**Picture** 69

**Pipette** 60, 101, 108, 145, 292

Fixed Pipette 101, 145

**Pixel** 52

**Pixel lock** 79

**Pixel zoom** 47, 201

**Plug&Play CMYK** 64, 93, 427

**Point** 52

**Polygon** 167, 382

**Pos./Neg.** 219

**Positive/Negative** 70

**PostScript-Printer** 422

**PowerMac** 19

**Preferences** 51, 110

**Prefs** 110. See Preferences

Prefs file 85

**Prescan** 83

Aborting Prescan 184

High resolution prescan 184

Prescan concept 83

Prescan design 84

Prescan faster 65

Prescan launch button 39

Prescan mirroring 40

Prescan monochrome 65

Prescan rotation 40

Prescan without auto focus 67

Saved prescan for reflective and for transparency  
84

**Preserve settings for a new image** 57

**Presets** 259, 267

**Preview in fullscreen** 43

**Preview mode** 270

**Primary colours** 452, 453

**PrinTao** 266, 270, 295, 298, 299, 405, 406

1:1 copy function 406

Adapt to page size 309

Add button 302, 306, 309

Additional pages 306

Centre image in printout 302

Centre on page 309

Changing the image clipping within the image  
frame 305

Click-dragging 308

Composing images and texts 328

Context menu 331

Control buttons 309

Copyright notes 317

Create freely positionable text framework 316

Crop image 304

Cut image 309

Cut image option 303

Delete button 309

- EXIF/IPTC data** 298
- Export** 309
- Export print documents** 318
- Grid frame** 327
- Help lines and grid frames on print pages** 326
- Image list** 405
- Invert button** 303
- Keyboard shortcuts in PrinTao** 332
- Layout menu** 307
- Load** 309
- Navigator / File Browser** 300
- Number of pages** 307
- Page and layout settings** 405
- Page number** 405
- Printer Settings** 405
- Printer setup** 331
- Printing area** 405
- Print single image** 302
- Priority** 307
  - Exact size 307
  - Long side 307
  - Small side 307
- Reflect vertically / horizontally** 309
- Rotate button** 303, 309
- Rulers** 405
- Save** 309
- Scaling** 323
  - Scaling images on a print page 324
  - Scaling images within the image frame 325
- Stacking sequence buttons** 309
- Templates** 298, 316, 319
  - Activate / Deactivate templates 322
  - Adapt template 320
  - Application of default templates 321
  - Apply to all pages 320
  - Create layouts 320
  - Delete image frame 321
  - Delete template 320
- Drag&Drop 321
- New template from page 319
- Template modifiers 320
- Undo 320
- Text tools** 309, 310
  - Close text box 310
  - Colour 312
  - Copyright note 317
  - EXIF 314
  - Font window 310
  - GPS 315
  - IPTC 314
  - Meta data 311, 314
  - Placement 313
  - Spell check 313
  - Text editor 310, 311
  - Text panel 310
  - Undo / Redo 311
- Tools** 405
- Transfer several images to printout** 306
- XML files** 318
- Zoom and scaling functionality** 323
  - Zoom print page document 323
- Printer resolution** 446
- Print image** 42, 294, 295, 405
  - PrinTao. See PrinTao
  - Printing contact sheets 282
  - Printing Directly out of the Prescan Window 294
  - QuickTime movies 309
- Process mode** 70, 287
  - Batch-Mode 70
  - Batch-Mode (File) 70
  - Normal 70
  - Normal (File) 70
  - To album 70
- Profiles for ColorSync (ICM)** 63
- Progress bar** 264
- Progressive JPEG** 245

Proportional scaling 78

## Q

**Q-factor** 447. See Quality factor

**Quality factor** 39, 76, 447

**QuickTime movie** 26, 34, 43

**Quit SilverFast** 39

## R

**Radius of densitometer** 53

**RAM** 19, 24

**RAW data format** 72, 259

    Conversion of RAW data files 263

    CR2 (Canon) 259

    CRW (Canon) 259

    CS (Sinar) 259

    DC2 (Kodak) 259

    DCR (Kodak) 259

    DNG (Adobe) 259

    ERF (Epson) 259

    Green arrow 263

    HDR (Leaf) 259

    Internal RAW data conversion profile for your  
    Camera 261

    K25 (Kodak) 259

    KDC (Kodak) 259

    Linear conversion of the RAW data 261

    MOS (Leaf) 259

    MRW (Minolta) 259

    NEF (Nikon) 259

    ORF (Olympus) 259

    PEF (Pentax) 259

    RAF (Fuji) 259

    RAW (Leica, Panasonic) 259

    Red square 263

    SR2 (Sony) 259

    SRF (Sony) 259

    TIFF (PhaseOne) 259

    Unconverted RAW data file 286

    What is RAW data? 344

    X3F (Sigma) 259

**Realtime correction** 56

    Realtime processing 83

**Realtime Histogram** 293

**Red eye correction** 43, 291

**Reduce window** 108

**Reflective** 70, 103

**Remove red eyes** 291

**Renaming images** 272

    Automatic re-naming while unloading 273

    Re-naming images automatically 273

**Rendering intent** 63, 423

    Absolute colourimetric 424

    Perceptual 423

    Relative colourimetric 424

    Saturation 424

**Reopen SilverFast after processing** 56

**Reopen SilverFast after scan** 56

**Reset all** 89

**Reset button** 39, 76

**Resize box** 37

**Resolution** 77, 448

    Calculating the Scan Resolution 447

    Effective resolution 77

    Input resolution 444

    Interpolated resolution 77, 444, 448

    Optical resolution 96, 103, 444, 448

    Optimal scan resolution 447

    Optimum scan resolution for inkjet printers 450

    Output resolution 448

- Scan resolution (dpi) 444, 447
- Screen resolution (lpi) 446
- Showing interpolated resolution 77
- Showing scan resolution 77
- Which resolution does SilverFast indicate? 448
- Retouching of images 401
- RGB (0-255 values) and CMYK (0 to 100% measurement) 53
- RGB or CMY 53
- ROOT 28
- Rotation 40, 282
  - Rotate 90° clockwise 47
  - Rotation Tool Palette 47
- Round magazine 239

## S

- Saturation 160, 161, 228, 293
- SC2G (selective colour to grey). See SilverFast-SC2G
- Scaleable prescan 202
- Scaling 76
  - Fixing output width and height 78
  - Fixing output width or height 78
  - Proportional Scaling 78
- Scaling factor 39
- Scan CMYK 427
- Scan faster 65
- Scan frame parameters 39
  - Activating Scan Frames 89
  - Copying parameters into another scan frame 90
  - Deleting a Scan Frame 89
  - Loading and saving single scan frame parameters 86
  - Moving and Copying of Scan Frames 90
- Scan mode 70, 87, 242
  - Batch 242
  - Batch mode 70
  - Batch mode (file) 70, 243
  - Batch scan 87
  - Normal 70, 242
  - Normal (File) 70, 242
- Scanner > Internal 62
- Scanner interfaces 21
  - FireWire 21
  - SCSI 21
  - USB 21
- Scanner with different optical resolutions 103
- Scanning concepts 443
- Scan parameters 69
  - Frame palette 71
- ScanPilot 39, 40, 110
  - Help texts 111
  - Preferences dialogue 110
- Scan resolution 39, 76, 77
  - Scan Resolution for Scaled Images 77
  - Showing interpolated resolution 76
  - Showing scan resolution 76
- Scan RGB 427
- Scan start button 39
- Scan type 39, 71
- Scratch volume 55
- Screening matrix 446
- Screen resolution (lpi) 446
- SCSI 21, 80
  - SCSI ID 21, 80
- Search for ... 269
- Sector correction. See Selective colour correction
- Selective colour correction 108, 158, 452
  - Activation of selective colour correction 159

- Administration of layers** 159
- CM12** 159
- CM6** 159
- Colour circle** 160, 164
- Colour matrix** 159, 160, 165
- Colour space zoom** 159
- Correcting an image selectively** 162
- Correction of 12 colours** 174
- HSL controls** 160
- Joining presets for a complete correction** 166
- Masks** 159
  - Brush tool 168
  - Changing a mask 171
  - Changing of a mask 170
  - Creating masks 159
  - De-activating a mask (no mask) 171
  - Directly new redraw of an inverted mask 170
  - Displaying an inactive mask area 172
  - Hard or soft mask edges 169
  - Inverse mask 170
  - Lasso tool 168
  - Mask edge size 169
  - Move a mask 171
  - New mask 168
  - Polygon tool 168
  - Removing a mask (delete) 172
  - Selecting a mask tool 167
  - Working with masks 167
- Multi layers and masks** 175
  - Changing layers (switching) 177
  - Creating new layers 176
  - Deleting layers 177
  - Moving of layers (change order) 178
- Objective of selective colour correction** 160
- Presets** 159, 165
- Reset / Reset all** 159
- Selecting colours** 164
- Working with colour correction presets** 166
- Separation parameter** 93
- Serial number** 29, 31
  - Problems while entering the serial number 33
- Setting** 73, 86, 88
  - Saving and Loading several Scan Frames as one Setting 88
- Settings SilverFast / Photoshop 5.02** 428
- Settings SilverFast / Photoshop 6** 431
- Settings SilverFast / Photoshop 7** 432
- SFLauncher** 22, 30
  - Launching and activating SilverFast via SFLauncher 30
- SF Statistic.txt** 189
- SFthumbs** 266, 268
- Shadow** 108, 141, 149
  - Setting shadow 124
- Shadow cast** 74
- Shadow offset (darkest point)** 59
- Shadow triangle** 121
- SilverFast...SE...** 133, 148, 155, 158, 187, 194, 200, 205, 215, 219, 233, 369, 378, 393
  - SilverFast...SEPlus 205
  - SilverFastSE 253
- SilverFastAACO** 44, 399
  - AACO 44
  - Auto Adaptive Contrast Optimization. See Virtual Light Table (VLT)
  - Saturation 400
  - Shadow width 400
  - Strength 400
- SilverFastACR** 179
  - ACR control 159
  - ACR slider 179
  - ACR with auto-adjust 61
- SilverFastAi...** 253
  - SilverFastAiStudio 253
- SilverFastAiStudio** 298, 405, 406, 409

- Image settings 409
- PrinTao (Extended print dialogue of SilverFastAiStudio) 405
- PrinTao dialogue 406
- SilverFastDC...** 253, 258
  - Album palette 267
  - Album window 278
    - Size of the album window 285
  - Alternative Opening of Images 256
  - Blue\* or Green Dots within the Thumbnails 277
  - Browser- and Navigation Window 266
  - Cache 259
    - Cache size 260
    - Delete 260
  - Contact sheet 282
  - Conversion of RAW data files 263
  - Deleting images 285
  - Differences in Calibration Between a Scanner and a Digital Camera 437
  - Edit image comments 281
  - EXIF 284
  - Export albums 271
  - File browser 300
  - Hide/Show button 268
  - Image settings 292
  - Internal RAW data conversion profiles 261
  - IPTC 272
    - IPTC image information in the album 283
  - JobManager 288
  - Magnifier 277
  - Manually selecting a camera specific ICC profile 262
  - Mark button 280
  - Open button 335
  - Overview window 268
  - Path for the Album Folder 259
  - Plus/Minus buttons 267
  - Presets palette 267
  - Preview mode 270
  - RAW data formats 259, 286
  - Re-naming dialogue 273
    - Add IPTC to file 274
    - Add the old index number to the name 274
    - Image list 273
    - Settings for new names 273
    - Subsequent, Automatic Renaming 276
  - Remove red eyes 291
  - Search button 269
  - Show EXIF data 277
  - SilverFastDCPro 254
  - SilverFastDCProStudio 254
  - SilverFastDCSE 254
  - SilverFastDCVLT 254, 258
  - System requirements 259
  - Unloading Camera Storage Media 271
    - Original 273
    - Output 272
    - Path 272
    - Possible actions 275
    - Preview 273
    - Re-naming Example 275
    - Renaming 272
    - Transformation 272
    - Workflow for unloading 271
  - SilverFastDCPro** 259, 261, 298, 336
    - DCPro open image 288
    - IT8 calibration 336
  - SilverFastDCProStudio** 298
  - SilverFastHDR** 298
  - SilverFastHDR...** 253, 255
    - Alternative Opening of Images 256
    - HDR open image 256
    - HDR overview 256
    - JobManager 288
    - Renaming images. See SilverFastDC...
    - SilverFastHDRStudio 253, 255

- SilverFastHDRStudio** 298
- SilverFastHiRePP** 338
  - Furnishing existing image data with HiRePP 339
  - HiRePP is especially significant for whom? 339
  - How does HiRePP function? 339
  - How much time will be saved? 338
- SilverFastiSRD** 41, 393
  - Activating iSRD 394
  - Auto 395
  - Combining iSRD and SRD 396
  - Expansion correction 395
  - Expert mode 395
  - How does iSRD work? 393
  - Infrared channel display 397
  - iSRD automatic mode 394
  - iSRD manual mode 395
  - Layers 396
  - Masks in iSRD 397
  - Prescan 395
  - Threshold value 395
  - Using SRD and iSRD simultaneously (layer technology) 396
  - Which films can iSRD be used with? 394
- SilverFastJobManager** 40, 288, 289, 343.  
See **SilverFastSC2G**
  - ... with film scanners and film strips 347
    - Activating the JobManager 347
    - Adding all frames of the preview window 349
    - Adding a single frame 350
    - Changing Back a Job 356
    - Choosing the location for scans 353
    - Easy-edit mode 351
    - File format 353
    - File naming menu 354
    - Image overview of inserted film strip 348
    - Index 355
    - Job status 356
    - Leaving the processing mode 352
    - Output settings 353
    - Processing mode 351
    - Produce job entries 347
    - Selecting desired images 348
    - Starting the real scan processing 355
    - Workflow with film scanners 357
  - ... with flat bed scanners 358
  - ... with SilverFastHDR..., -DCPro... 359
    - Differences in working with scanners 359
  - Differences in JobManager between SilverFastHDR..., -DC..., and SilverFastAi...** 346
  - Difference to working with film scanners** 358
  - Error messages** 366
  - How is JobManager different from batch scanning?** 344
  - Image information** 346
  - Job entry** 344, 347, 361
    - Copying of complete job entries 362
    - Copying of job entry parameters 361
    - Deleting job entries 350
    - Processing job entries 351
  - Managing complete jobs** 363
  - Multit job** 363
  - Name of current job** 346
  - Output options** 346
  - Overview** 345
  - Processing time - example** 359
  - Purpose of the JobManager** 343
  - Save as** 363
  - Tools** 346
  - Unconverted RAW data images** 288
  - What is a Job?** 344
  - What is the JobManager?** 343
  - Workflow** 364
- SilverFastNegaFix** 70, 233
- SilverFastPhotoProof** 298, 299, 331
- SilverFastSC2G** 180
  - Activating SC2G 180

- Changing a colour image to grey 181
- Changing the conversion factors 183
- Saving / loading / deleting SC2G settings 182
- SilverFastScanPilot** 351
- SilverFastSRD** 41, 369
  - Administration of layers 371
  - Activate / Deactivate realtime correction 377
  - Activating SilverFastSRD 375
  - Activation of SilverFast dust and scratch removal 371
  - Auto 375
  - Continuity 387, 392
  - Contrast 387, 391
  - Control buttons 371
  - Control menu 371
  - Creating masks 371
  - Defect recognition 379
  - Defect size 379
  - Defect type 379, 387, 388
  - Delete Resources 385
  - Detection 379
  - Environment size 381, 386
  - Expert mode 371, 386
  - Extension 386
  - Intensity 379, 380
  - Layers 383
    - Add layer 384
    - Move layer 384
    - Multiple layers 383
  - Length 387, 389
  - Longish scratches 387
  - Manual correction 378
  - Masks 371, 382
    - Adding to mask 383
    - Drawing a mask 382
    - Drawing an inverted mask 383
    - Mask tools 382
    - Selection of mask tool 382
    - Subtracting from mask 383
  - Monitor modes 376
    - Artifacts highlighted 377
    - Corrected view 377
    - Original view 377
  - Navigator 376
  - Navigator window 371
  - Orientation 387, 388
  - Output resolution 374
  - Overview 371
  - Presets 371
  - Preview 375
  - Red framed tile 376
  - Save / Load settings 385
  - Using SRD and iSRD simultaneously (layer technology) 396
  - View of artifacts 371
  - Width 387, 390
  - Workflow 372, 373
  - Yellow framed tile 376
- Size adjustments / scaling** 76
- Skin tones** 74
- Snow** 74
- Soft mask** 57
- Softproof** 91, 195, 416, 427
  - Changing the separation parameter and control on the effect of shadow-build-up 93
  - Softproof of CMYK colour separations 92
- Sorting images** 279
- Special defaults palette** 65
- Special functions** 39, 193
- Specular highlights** 130, 141
- SRD.** See SilverFastSRD
  - SRD (Smart Removal of Defects) 369
- sRGB** 416
- Stand-Alone-Application.** See SFLauncher

**Start volume** 21  
**Studio upgrade** 253  
**Studio versions** 401, 405  
**Super fine scan** 67  
**Switching scanners** 80  
**Switch SilverFast from RGB to CMYK** 427  
**System requirements** 19, 259

- Macintosh 19
  - 68k 19
- Windows 20

## T

**Technic** 74  
**Templates** 298, 316, 319. See PrinTao

- Default templates 321
- Modification of templates 319
- View templates 301

**Text tools.** See PrinTao  
**Three-step slider** 155  
**Threshold** 59, 119, 200, 213, 216

- Auto threshold highlight 121
- Auto threshold shadow 121

**Thumbnail size** 268  
**Toggle switch** 195  
**Tool bar in the prescan window** 40

- Auto-adjust 46
- Expert dialogue 46
- Global correction 46
- Gradation 46
- Histogram. See Virtual Light Table (VLT)
- Reduce window 46
- Selective colour correction 46
- Setting highlight / mid tone / shadow 46
- Zoom 46

**Tools for brilliant images** 107

**Tools palette** 39, 108

- Tools 46, 108

**Transparency** 70, 103  
**TWAIN** 25

## U

**Uneven scaling of images** 77  
**Units of measurement** 52, 53  
**Unload images** 271  
**Unsharp masking (sharpness)** 73, 199, 209

- Automatic USM 199
- Manual USM 199
- Manual USM in the expert dialogue 203
  - Light contour / dark contour 203
  - Over sharpening 203
  - Shadows soft 204
  - Sharpen from (only in negative-mode) 203
  - Sharpening up to 203
- Matrix 200
- Pixel zoom 201
- Setting of the output parameters 199
- Strength 200
- Threshold 200
- USM dialogue with scaleable prescan 202
- Zooming into the Preview 201

**Update reminder** 33  
**Upgrade button** 32  
**USB** 21, 80  
**USBSCAN.SYS** 21  
**User defined** 74  
**User forum** 27  
**USM** 209, 374. See Unsharp masking (sharpness)

## V

**Vertical scaling** 76

**Virtual Light Table (VLT)** 42, 255, 265

- Album window 278
- Arrangement of the VLT 265
- Blue\* or green dots within the thumbnails 277
- Drag & Drop 279
- Edit name and image comment 281
- Export button 287
- JobManager 288
- Keyboard shortcuts 290
- Launching the Virtual Light Table (VLT) 265
- Magnifier 277
- PrinTao in VLT 299
- RAW data file 286
- Rotating and flipping images 282
- Size of the miniatures 281
- Sort images by drag & drop 279
- Sort images by marking 280
- Workflow example 289

**VLT** 255, 265, 340. See Virtual Light Table (VLT)

**Densitometer** 186

**Editing a zoomed prescan** 102

**Magnifyer turns green** 100

**Magnifyer turns red** 100

**Zoom and difficult corrections** 101

**Zooming by click-dragging the mouse** 99

**Zooming by mouse click** 97

**Zooming by the zoom display popup** 98

**Zooming in the Prescan** 95

**Zooming in the prescan** 184

## W

**Welcome dialogue** 26, 57

**White Bbalance** 292

**Workflow of optimising images** 113

## X

**XML files** 318

## Y

## Z

**Zoom** 95, 97, 108, 184, 323





## Chapter 7.5

## Glossary



## 7.5 Glossary

### A

#### **additive primaries**

Red, green, and blue light that produce white light when added together.

#### **ASCII**

(American Standard Code for Information Interchange) A standard format for representing data or text in 8-bit chunks.

### B

#### **bit**

(binary digit) The basic unit of information used by computers. It has two states: on or off.

#### **bitmap**

An image made up of a matrix of dots, or pixels.

#### **byte**

A unit of information equal to eight bits.

### C

#### **calibration**

The process of setting equipment to a standard measure.

#### **CCD**

(Charge-Coupled Device) A light sensitive electronic chip used by scanners to measure light.

#### **channel**

One greyscale scan or one of the three RGB components making up a colour scan.

#### **CLUT**

(Colour Look-Up Table) A collection of most-often-used colours stored in a file or the System.

**CMYK**

(cyan, magenta, yellow, black) The subtractive primaries, also known as the process colours, used for colour printing.

**Colour separation**

Dividing a colour image into its four CMYK components for printing. (Also refers to the C, M, Y or K film negative from which printing plates are made.)

**comp**

(comprehensive) A test print used to evaluate layout and design.

**compression**

The process of decreasing a file size.

**contrast**

The range between the darkest and lightest areas in an image.

**D****daisy-chain**

link together sequentially as in linking multiple drives on the SCSI bus.

**DCS**

(Desktop Colour Separation) A format that contains five Post-Script files for each colour image.

**densitometer**

A hardware device to measure the amount of light transmitted through film to check the quality of imagesetter output. Also a software feature for measuring the grey and RGB levels of an on-screen image.

**dithering**

A halftoning process that uses clusters of dots rather than evenly spaced halftone cells.

**dot gain**

A printing defect in which halftone dots print larger than intended.

**dpi**

(dots per inch) The unit of measure for a printer's output resolution. Also used for scanner resolution although ppi or spi is more accurate.

**dropout colour**

A colour that you set the scanner not to recognise.

**E**

**EPS**

(Encapsulated PostScript) A file format that can contain both scanned images and PostScript images along with printer information.

**gamma**

A measure of contrast that affects the midtones of an image.

**gamma correction**

Application of an algorithm to correct images for the fact that machines and people perceive tonal gradations differently.

**G**

**GCR**

GCR (Grey Component Replacement) A technique for reducing the amount of cyan, magenta, and yellow ink in an area and replacing them with black ink.

**Greyscale**

An image type made up of black, white, and grey pixels. Also, the range of greys in such an image measured in either percent black (0% is white and 100% is black) or grey levels (0 is black and 255 is white).

## H

### **halftone**

An image that uses different sized dots to represent light and dark areas.

### **highlights**

The white and nearly white parts of an image.

### **histogram**

A bar graph of the number of pixels for each grey or RGB value in an image. The histogram helps you evaluate the tones in an image.

### **HSB**

(Hue, Saturation, Brightness) A colour model that defines a colour by specifying its hue, saturation, and brightness.

## I

### **imagesetter**

A printer that prints computer files at high resolution on photographic paper or film.

### **interpolation**

Mathematical calculation the scanner performs to increase resolution.

## J

### **JPEG**

(Joint Photographic Expert Group) A compression algorithm for image files.

## K

### **kilobyte**

A unit of memory equal to 1024 bytes.

## L

### **Line art**

An image type made up of black and white pixels only.

### **lpi**

(lines per inch) The unit of measure for halftone line screen frequency, or how many halftone cells occur in an inch.

### **LUT**

(Look-Up Table) The table of colours a computer can display at a given time.

## M

### **megabyte**

A unit of memory equal to 1024 kilobytes.

### **memory**

Computer hardware that can store information for later retrieval. This term can mean either hard disk memory or RAM memory. See also RAM.

### **midtones**

The range of tones between the shadows and highlights of an image.

### **moire**

Undesirable banding when scanning a halftone image due to the halftone screen interacting with the scanning grid.

## O

### **overprinting**

Printing over areas already printed, as opposed to using a knockout.

## P

### **PICT**

The native Macintosh file format for images.

### **pixel**

(Picture Element) The smallest point in a scanned image. Line art pixels are black or white, greyscale pixels can be from grey level 0 to 255, and colour pixels can be from 0 to 255 for each RGB channel.

### **Plug-in module**

Software that runs from within another application.

### **posterisation**

Visible tonal banding in an image.

### **ppi**

(pixels per inch) The unit of measure for a pixel based image, such as an image displayed on a monitor. Also used for scanner resolution.

### **prepress**

The industry that prepares the film from which printing plates are made.

### **preview**

A low-resolution version of an image that appears in the *Silverfast®Ai* Preview window to help you set the scan area and scanner controls.

### **proof**

A representation of what a final printed piece will look like so that it can be evaluated before the expense of printing.

## R

### **RAM**

(Random Access Memory) The short term chip-based memory in a computer that applications load into to run.

### **RGB**

(Red, Green, Blue) The additive primary colours used to display images on a monitor.

## S

### **scan head**

The part of the scanner containing fluorescent lamps that passes across an image.

### **screen frequency**

See lpi.

### **SCSI**

An acronym for Small Computer System Interface. An industry standard interface that provides high-speed access to peripheral devices.

### **SCSI chain**

A group of SCSI devices linked to each other through SCSI peripheral interface cables and linked to the SCSI port on the computer through a SCSI system cable.

### **SCSI ID number**

A number assigned to each SCSI device connected to a computer. The Macintosh itself is assigned ID 7. Other devices may use IDs 6 through 0, with 6 indicating the highest priority for communications and 0 the lowest priority.

### **service bureau**

A business that specialises in printing computer files on an imagesetter.

### **shadows**

The black and nearly black tones in an image.

**stripping**

The traditional process of assembling colour separations and typeset text by hand prior to making printing press plates.

**subtractive primaries**

The ink colours cyan, magenta, and yellow that add together to make black.

**T****terminator**

A device used in an SCSI chain to maintain the integrity of the signals passing along the SCSI chain. An SCSI chain should have one terminator at the start and end of the SCSI chain.

**TIFF**

(Tagged Image File Format) A file format for exchanging files between applications and computers.

**trapping**

A technique of overlapping abutting colours to compensate for printing press misregistration

**U****UCR**

(Undercolour Removal) A technique for reducing the amount of magenta, Yellow, and cyan ink in neutral areas of an image and replacing them with an appropriate amount of black ink.

## V

### **virtual memory**

A feature of some applications (and System 7) that lets you use hard disk space as RAM.









En  
02/2010

LaserSoft Imaging AG  
Luisenweg 6-8  
24105 Kiel • Germany  
Tel.: +49 (0) 431/5 60 09-0  
Fax: +49 (0) 431/5 60 09-96  
E-Mail: [Info@SilverFast.com](mailto:Info@SilverFast.com)  
[www.SilverFast.com](http://www.SilverFast.com)

**LaserSoft Imaging®**

©2008 SilverFast® and LaserSoft Imaging™ are registered trademarks of LaserSoft Imaging AG, Germany.  
All mentioned trademarks are the protected trademarks of the respective owners.  
Patents: EP 1594301, EP 1744278